

Figure 1

200




Figure 2




Figure 3




Figure 4A




Figure 4B

Image Recovery




Figure 4C




Figure 5





Figure 6

Figure 7A: Injector Status LED

Steady Green	ODU passed POST and Loaded software image
Blinking Green	DC power applied, ODU is loading software or going through POST
Blinking Amber	ODU is not discovered, DC power not applied.
Steady Amber	Recovery button is pressed more than 2 second and less than 20 sec, ODU is in Configuration recovery mode
Steady red	Recovery button was pressed more than 20 sec, ODU is in Image recovery mode, downloading new image.

Figure 7B: Power LED

Black	No DC power is applied to SPIER
Steady green	DC power is applied to SPIER

**Figure 8**